



In the Box

1 x MZX634 Earphones
1 x Charging Case

Micro USB Charge Cable

L, M, S Ear gens

A Closer Look

LED Indicator

Button

Microphone

Charging Contacts

L

Charging

2-3 Hours Full Charge

- <30%
- =30-70%
- >70%
- =100%

*Lights Will Flash When Charging

● Red= Charging
○ Off = Charged

*Please note that the LEDs on the earphones will turn blue before turning off completely when fully charged.

Bluetooth® Pairing

1

Open the charging case and take the earbuds out, earbuds turn on and pair automatically.

2

Enable Bluetooth on your device and select "True Evo Air".

*The earbuds turn off automatically when you put them back to the charging case.
To manually power on/off, long press both buttons for 3 seconds.

Controlling Your Earphones

One Click: Play/Pause/Answer Incoming Call

Two Rapid Clicks: Start Voice Assistant

Hold 2-3 Seconds: Reject an Incoming Call

Hold 5 Seconds: Power Off

*The left earbud can be used alone, while the right one can't.

*- To use Siri or Google Assistant, you must have a phone that is compatible with one of those two voice assistants (iOS or Android, respectively).

- Your Wireless Earphones will not work with Siri or Google Assistant if the assistant is not first enabled within the settings on the phone. For more information, see your phone's user manual.

- You must be within Bluetooth® range to use Siri or Google Assistant via your Wireless Earphones.

Wearing Your Earphones

6 6 6

For additional user materials and warranty information, please visit alteclansing.com

est.
FIRST

FOLLOW US ON #myalteclansing